

XPressEntry / Kantech EntraPass

Revision 1/11/2024

For use with the XPressEntry Mobile Access Control System

By



Important Notice

Your right to copy XPressEntry software and this manual is limited by copyright laws. Making copies, adaptations, or compilation works (except copies of XPressEntry software for archival purposes as an essential step in the utilization of the program in conjunction with the equipment), without prior written authorization of Telaeris, Inc., is prohibited by law and constitutes a punishable violation of the law.

This software and documentation are copyrighted by Telaeris, Inc. The software and documentation are licensed, not sold, and may be used or copied only in accordance with the Telaeris License Agreement accompanying the software.

© 2023 Telaeris, Inc.

All rights reserved worldwide.

Information in this document is subject to change without notice.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, scanning, digitizing, or otherwise, without the prior written consent of Telaeris, Inc.

Trademark Acknowledgements XPressEntry is a trademark of Telaeris, Inc.

Other company and product names may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Telaeris, Inc. 4101 Randolph Street San Diego, California 92103 United States of America

(858) 627-9700

www.telaeris.com

Contents

Purpose4
Pre-requisites/Requirements4
Setting Up Kantech EntraPass to Synchronize with XPressEntry 4
Connected Program Licensing 4
Kantech Operator
Enable XPressEntry Synchronization5
Data Manager Tab5
Sync Timers ϵ
Sync Options
Kantech Data Manager Setup Page
XPressEntry Data
Users
User Permissions
Doors
Activities
Kantech Sync Check 12
Kantech – XPressEntry Mapping 12

Purpose

This document is intended to instruct users on how to synchronize an XPressEntry system with a Kantech **EntraPass** system. XPressEntry has the capability of providing access control management from a handheld device. For XPressEntry setup information, see the document, "XPressEntry Installation and Upgrade" found at <u>https://telaeris.com/documentation</u>.

Pre-requisites/Requirements

- 1. XPressEntry 3.5+
 - a. Installed, with network access to Kantech web service.
- 2. Kantech EntraPass v.7.3-8.6
- 3. SmartLink SDK software
- 4. Connected Program license

For more information on Kantech service, please contact Kantech Support.

Setting Up Kantech EntraPass to Synchronize with XPressEntry

It is assumed that a version of EntraPass and XPressEntry are installed on computers or virtual machines that can talk to each other, or the same computer or virtual machine. To install XPressEntry, you should have Administrator privileges on its respective machine. You should additionally be an Administrator or super user in the Kantech EntraPass System.

Connected Program Licensing

Beginning with version 7.3, EntraPass needs to be licensed by Kantech to sync data from the system. Licensing can be procured through your authorized Kantech reseller.

kegistration		×
	System serial number	215D C6E8 5C86 237C
	System Components - Features All components System option System option	Alternate type Options serial nun 215D-C6E8-5C86-
Optional or additional system components	 EntraPass Web (1) Connected program (1) 	5ADF-7DC0-C45C Xpressentry (Telaeris) 2980-4E48-06CA-9C
3rd party video integration Connected program Enterprise KAP EntraPass LDAP EntraPass Token EntraPass Web go Pass HID Mobile Access Honeywell Galaxy KTES (3000 tenants)	Components	Installation codes
Licensed door Mirror Database and Redundant Server Multi-Site Gateways		No data to display
View EntraPass KAP details	Activate Edit	🚔 Print
		0

To apply the **Connected Program** license:

- 1. Navigate to the **Registration** section of the EntraPass workstation or server app.
- 2. Select the Connected Program option from Optional or additional system components.
- 3. License the Connected Program by contacting the Tyco Licensing system. Once licensed, Connected Program will appear in the **System Components > Features** section.
- 4. Initially, Alternate type will be empty. Select Connected Program from the grid and click Edit.
- 5. Select **XPressEntry**, and then click **OK**.
- 6. Lastly, close the registration form.

*Note: Restarting EntraPass services is required before XPressEntry will be able to pull data from Kantech.

Kantech Operator

Once the Connected Program is registered, the installer will need to create an Operator that XPressEntry will use to log into the integration. The Operator must be defined as administrator.

Enable XPressEntry Synchronization

XPressEntry uses a module called **Data Manager** to synchronize all data with EntraPass. From the main page of XPressEntry, go to XPressEntry > Settings (**ALT+S or Tools > Settings**).



Data Manager Tab

From the Settings page select the Data Manager Tab.

1. **Type** – This is the integration type. Select **KANTECH** > **Add** > **Save**.

- 2. Go to **Data Manager > KANTECH** in sidebar menu.
- 3. Setup Data Manager This sends you to the setup form for Kantech's data manager.

File Database SQL Import/Expor	P	~ Add	Remove
General	Type KANTECH	Add	Remove
Add / Edit Display			
Badges	Name KANTECH	Prefix	
RFID User Defined Fields			
Muster Settings			
Question Setup	KANTECH - Prefix()		
Logging			
Client Settings			
Wiegand Format Data			
Server			
Service Settings Database			
□ Data Manager			
Software Event Viewer			
Reader Profiles			
Handheld Functionality			
Reader Validations			
Passwords			
Badge Settings			
Custom Display Validation Colors			
Doors			
Trend Settings			
Alert Settings			
Email Settings			
Twilio Alerts			
		Sanity C	Check Data

Sync Timers XPressEntry uses Timers to pull Kantech Data into XPressEntry.

e Database SQL Import/Ex							
	Enable Data Manager	Type: KAN	TECH			Setup	Data Manager
ieneral							
Add / Edit Display Badges	Sync Timers Sync Optio	ns					
RFID			- ·			-	
User Defined Fields			Concurrent			Send XPressEr	ntry Activities N
Muster Settings		s	yncs				
Question Setup							
Logging	Download Activity Frequency			Set	Clear	Download	Activity Now
Client Settings							
Wiegand Format Data					0		0
erver	Occupancy Sync Frequency			Set	Clear	Occupanc	y Sync Now
Service Settings							
Database	Partial Sync Update			Set	Clear	Partial S	Sync Now
ata Manager KANTECH	Frequency						
Software Event Viewer					1		
leader Profiles	Full Sync Update Frequency			Set	Clear	Full Sy	ync Now
Handheld Functionality							
Reader Validations	Custom Sync Update			Set	Clear	Custom	Sync Now
Passwords	Frequency						
Validation Colors Doors Trend Settings lert Settings Email Settings	Data Manager Live Log View	Pause	Mirror Log To:				Browse
Twilio Alerts	DEBUG: DataManager Settings Update						
	DEBUG: DataManagers Restarted						

- 1. **Download Activity Frequency** Pulls reader scan records into XPressEntry and stores them in XPressEntry's activity table. This function also updates the zone occupancy.
- 2. Occupancy Sync Frequency Updates the zone occupancy without storing the activity records.
- 3. **Partial Sync Frequency** Pulls all data excluding cardholder data, including readers, areas, access levels.
- 4. **Full Sync Update Frequency** Updates all tables by pulling all necessary records from eFusion. This function may take some time.
 - a. It is recommended to run a full sync **once per day** in the middle of the night when the system is not busy.
- 5. Custom Sync Frequency Updates a set of tables that the user configures.
 - a. To configure, right click **Custom Sync Now** and select **Edit Custom Sync**.

Custom	Table Sync				_		
	Add Table					Done]
Table	USERS	✓ ✓ Partial?	(3) Table	BADGES	✓ ✓ Partial?		
Table	GROUPS_USERS	✓ Partial?	0				

Sync Options

XPressEntry Settings		-	- 0	×
File Database SQL Import/Export				
	Enable Data Manager Type: KANTECH	Setup [Data Manag	jer
 ☐ General Add / Edit Display Badges RFID User Defined Fields Muster Settings Question Setup Logging Client Settings Wiegand Format Data ☐ Server Service Settings Database ☐ Database ☐ Database ☐ Database ☐ Database Event Viewer ☐ Reader Profiles Handheld Functionality Reader Validations Passwords Badge Settings Custom Display Validation Colors Doors Trend Settings ☐ Hart Settings ☐ Kalert Settings 	Sync Timers Sync Options Pull DataManager Occupancy Event Processing Retry Cou Default Outside Zone V Pull Data Manager Activities into XPressEntry DMPrefix Pull Data Manager Activities to Data Manager Default Outside Sone			×
	Clear Data Manager Settings Clear External D Data Manager Live Log View Unpause	'ata	Browse	
		Save	Car	ıcel

- 1. **Pull Data Manager Occupancy** Enables use of the Occupancy Sync.
- 2. Pull Data Manager Activities into XPressEntry Enables use of the Activity Sync.
- 3. Push XPressEntry Activities to Data Manager Enables XPressEntry to push Scan

data to Kantech.

- 4. **Send Activities Retry Count** Number of times XPressEntry will attempt to resend an activity if it fails.
- 5. **Default Role** The default XPressEntry Role that will be assigned to users if the integration does not otherwise assign a role. Entrants are recommended but not required.
- 6. **Muster Scanned Users** Enables sync to convert scans from specific readers to be converted into Muster Scans which mark users as safe. Muster readers must be configured in the reader data. Please see *Mustering Documentation* for more details.
- 7. Setup DataManager Button Opens Kantech specific settings.
- 8. **Clear DataManager Settings** Resets all settings on the two above tabs, as well as the Kantech specific settings.
- 9. Clear External Data Deletes all data synced from Kantech from the XPressEntry Database.

Kantech Data Manager Setup Page

*Note: If you have already established a connection with Kantech, make sure only one login is going at a time. When you go to the setup form, disable all syncs and turn off the table watcher. Then press Save. Then go into the Settings form. This prevents us from opening multiple sessions to Kantech at a time.

Press the **Setup Data Manager** button to get the Kantech specific setup screen. In the new window, you will see the following:

Kantech Setu	tech Setup — 🗆								\times
Database U	tilities								
General									
User:	kantech					Users Per Cycle	: 1000		* *
Password:	•••••				E	Badges Per Cycle	: 1000		-
Server:	kantech86.ad.tela	eris.com:880							
Use HT	TPS				Pic	tures Per Thread	1: 500		-
Encrypt Login (required in Kantech V7.3 and greated in			ind greater)		Re	port Pictures Pe	r: 100		-
Pull Muster Tables Only							1		
Use Advantage Data Connector For Muster					Up	date Pictures Pe	r: 1000		*
Event IDs to Process 201 Time Between Wat						tcher Check (ms): 10000		A
Connected Program Number: 8e2866d1-7dfb-46db-8cbe-ff5870faccae									
Log Incomming Event IDs				(Jear		onnect		
Users, Badges, and Pictures Only				,			onneet		
Successfully of	connected to the w	veb client!							\sim
									\sim
Sites	Sites Check All Uncheck All 82								
🗸 Telaeris C	Connection								
						Save	e and Clo	se	

1. User and Password – The username and password of the Kantech Operator that was created.

- 2. Server The location of the Kantech SmartService route, including the port.
- 3. Use HTTPS Select if SmartService uses https.
- 4. Encrypt Login Beginning with Version 7.3, the login sent to Kantech must be encrypted. Select this setting.
- 5. **Connected Program Number** Provided by Telaeris on all installations to Kantech Systems that are version 7.3 or greater.
- 6. **Users per Cycle** The number of users XPressEntry will query at in a single request.
- Pictures per Thread The number of pictures a single thread will be responsible for downloading from XPressEntry. This will determine the number of threads XPressEntry creates to simultaneously query Kantech's system.
 - a. e.g. With **1000 users** in the database, **100 pictures per thread** will create **10 threads** to asynchronously download pictures. Use this setting to optimize your sync times.
- 8. **Report Pictures Per** Declares how often the software reports the number of pictures downloaded during a sync. **Information logging** must be turned on to view this.
- 9. Update Pictures Per How often the system will update pictures pulled from our threads. Use this setting to optimize sync times.
- 10. Time Between Watcher Check (ms) Not used at this time.

Once the settings have been correctly set, select **Connect**.

- If the connection is successful, it will respond with, "*Successfully connected to the web client!*"
- If it is not successful, an error message will appear. In the case of an error message, there are a few things that you can check:
 - If the server location is correct
 - If Kantech's web service port matches the port specified in XPressEntry
 - If the firewall on Kantech's machine is turned off for the specified port
 - If all Kantech services are running

Once XPressEntry is successfully connected to Kantech's web service, you must configure which sites XPressEntry will pull data from.

- 1. Select **Fill Sites List**. The list of sites will populate below.
- 2. Select the **Site** or **Sites** that you want to pull data from.
- 3. Select **Connect** again, and then **Save**.

Once completed, close the Kantech Setup form. Select **Save** on the main settings page. You are now ready to sync.

XPressEntry Data

After setting up the data manager, run the initial **Full Sync** to pull data from Kantech. Once the Kantech System is set up and synchronizing, you will see this data represented in XPressEntry under the **Add/Edit Info** tab.

Data which is imported from Kantech cannot be changed and is greyed out in XPressEntry without proper permissions.

Users

Here is a sample of a properly synchronized user:

All External Records (From Kantech) will

display in red as an **External Record** at the top of the form. This label will not display for any records that were created from within XPressEntry.

XPressEntry will pull the user's **image** and **badge number** from Kantech. The badge number can be seen at the bottom of the screen.

	Sample Conta	ct Info UDFs/Misc Last Name Bell mpany 07/20 10:26:49 AM	MI	Photo FP	nes 🛍 Badge Types 🐏 M
Monica Company Emp ID	Sample Con Building 1 Zone Entry	Bell mpany : 07/20 10:26:49 AN	Visitor	Photo FP	
Company Emp ID	Sample Co Building 1 Zone Entry	mpany : 07/20 10:26:49 AN	Visitor	6	
Emp ID	Building 1 Zone Entry	: 07/20 10:26:49 AN	Visitor	6	
	Zone Entry		V Host	6	-
Zone	Zone Entry			D	-
			И		
Role	Entrant		~	Change Cro	p Delete
				Change ore	
Badges (0)	Add Ba	idge 😵 Dele	te Badge 💿 Vie	w History 🚔 Print Ba	adge
Badge	в	IDF1	Activated	Expired Date Invalid	Badge Type
			5/27/2020		
	(0)	End Date	End Date	End Date Badges Add Badge O Delete Badge Vie Badge BDF1 Activated Date	End Date Badges Add Badge O Delete Badge O View History Print Ba

User Permissions

Users in XPressEntry have the **same permissions** to each reader as they do in Kantech. This is regardless of whether the user is assigned an Access Code, Reader Group, or direct access to a Reader.

🛃 XPressEntry - 3.5.6413 - Telaeris (Logged In User: Adm	inistrator, Company)	– 🗆 X
🔨 Eile 🎬 Tools 🐼 View 🔬 Logout	Entry/Exit 🕅 Muster	Relp
Entry/Exit Muster Events HealthCheck Activity History Messa	ages Add/Edit Info Logs	
Filter: Image: Company Baderas, Antonio Image: Company Baderas, Antonio Image: Company Baderas, Antonio Image: Company Clooney, George Crain, Samuel Frey, George Gale, Sarah Gheller, Henny Jenkins, Winford Jenkins, Winford Kemp, Mark Lehmen, Corey Louic, Hannah Marshail, James Pennington, Matt Thomas, Michelle Image: Company	Companies & Groups & Zones User Permissions Contact Info UDFsMisc Access Groups Access Direct Zone Permissions Come Name Alowed Times Timezone Start EndTime Mon	Doors Caleaders & Roles Timezones Badge Types W
Time to Read 15 Records: 1.84 seconds	Add New Delete Save	e Cancel

Activity Occupancy Partial Full | Total Occupancy: 6 Inside 1 Zone | 0 Unread Messages | Service Running Locally

Doors

Entry/Exit permissions in XPressEntry are set by doors. Doors contain **two readers** – an exit and an entry **reader**.

Door access is determined by the user's access to the door's reader. For **entry**, permission is based on the user's access to the door's **external entry reader**. For **exit**, permission is based on the user's access to the door's **external exit reader**. Doors should be set by the user for each Handheld Reader in XPressEntry.

👂 🐺 Desktops Status Operatio	n Users Definition Groups De	vices Video System Re	ort Options		۵ 😒	🕽 🖏 XPressEntry (Administrator) - 3.0.999 - Telaeris Inc (Logged In User: Administrator, Company) - 🗆 🗙
Application Gateway Site (Connection Controller KTES	Door Relay	Input Output Reade templat	n Integrated Association		File PT Tools 🛞 View 👞 Logout Spfritty/Exit
						Entry/Ext Activity History Messages Add/Edit Info Logs
🖉 Door						Filter: 📃 🖉 🖷 🧿 🦓 Users 🔝 Companies 🏶 Groups 🧏 Zones 📃 Doors 🗋 Readers 💩 Roies 💿 T 💶
1 H H 🗙 🖶 📕	L Q					Lobby Door Door Name
Site filter	All connections and sites		✓ English			Lobby Door
			Lobby Door			Start Zone
Gateway	💿 01 - Multi-Site Gateway					Outside v
Connection	Telaeris Connection		<u> </u>			End Zone
Door	Controller #1 (0001)					Building v
Loor	 Lobby Door (01.01.1) Lobby Door - Exit (01.01.2) 					Door RFID Tag#
General Contact REX Miscellaneou			s level Trigger and Ala	arm Comment		
Door lock mode	Door access delay		oor access delay		-	External Entry Reader
Fai-secure Fai-safe	Unlock time (hh:mm:ss)		(hh:mm:ss)		00:0	Lobby Door (01.01.1) V
	Open time (hh:mm:ss)		hh:mm:ss)		00:0	External Exit Reader
Miscelaneous Elevator cab	Enable Multi-Swipe	Unlock sch	dule			Lobby Door - Exit (01.01.2) V
	Chable Multi-Swipe				_	
In/Out Type	None	V First P	rson In			
-Door Anti-Passback						
Туре	Entry	~				
		Camera / Vic	to View			
		Councilia -			~	Time to Read 1 Records: 0.02 seconds Add New Delete Save Cancel
	.				>	Activity Occupancy Partial Full Total Occupancy: 0 Inside 0 Zones 0 Uniread Messages Service Purning Locally
1/11/2024 12:59 Instale	r 🤝 0	0 😝 4 😝	27.0.0.1 🔵		.:	Activity Occupancy Partial Full Total Occupancy: 0 Inside 0 Zones 0 Unread Messages Service Punning Locally

- 1. For each door, set the **start** zone to **the area you will be exiting to** and the **end** zone to **the area you will be existing from**. This helps to determine directionality.
- 2. For proper **occupancy tracking**, set the start and end zone to zones created in the **Zones** tab.
 - a. Start zone The area the user will exit to.
 - i. **External Exit Reader** will be assigned to the Kantech Reader created for Exit if there is one.
 - b. End zone The area end user will enter to.
 - i. **External Entry Reader** will be assigned to the Kantech Reader created for Entry.

Activities

XPressEntry will synchronize activities to Kantech if that option has been set by the Data Manager. Entry/Exit activities will be sent to Kantech and display the results in the Transaction logs.

Activities will display in Kantech with the last associated timestamp on the handheld device. If the handheld device is off and then is turned on and syncs manually, it will display the time of when it was turned on as the sync time.

Kantech Sync Check

Kantech -	XPressEntry	Mapping
		P P O

Kantech	XPressEntry
Cardholders	Users
Card	Badge
Photo	Photo
Site	Company
Access Level	Group
Access Level Door	Group Reader
Cardholder Access Level	Group User (Permissions)
Doors	Doors
Doors	Readers

Once the initial sync is completed, check the Add/Edit Info tab on the server to determine if all the Kantech data fields listed above were successfully pulled into XPressEntry.